



PV Master APP




SEMS Portal APP



LinkedIn



Company's official website



ES QUICK INSTALLATION INSTRUCTIONS

PART 1


QUICK
INSTALLATION

PART 2

BATTERY
CONNECTION

PART 3

Wi-Fi
CONFIGURATION




340-00003-03


Step 1. Instructions for quick installation

A Installation space


Upward ----- 300mm
Downward ----- 500mm
Front ----- 300mm
Left and right side ----- 200mm




B Dimensions for drilling holes





C Fix the wall bracket



D Installation




E Battery wiring assembly and connection




F DC Cable assembly and connection

⚠ DC cable should be dedicated PV cable (suggest using 4mm² PV1-F cable)



G AC cable assembly and connection



Make sure the cables (L/N/PE) are connected to right position

Step1
Instructions for quick installation



Step2
SOP of battery connection

Step3
Wi-Fi configuration instruction

H DRED cable assembly

! DRED connection is only available for Australia and New Zealand.

NO	1	2	3	4	5	6
Function	DRM1/5	DRM2/6	DRM3/7	DRM4/8	REFGEN	COM/DRM0





1. Plug out the 6-pin terminal and dismantle the resistor on it.
2. Plug the resistor out, leave the 6-pin terminal for next step.

Note: The 6-pin terminal in the inverter has the same function of DRED device. Please leave it in the inverter if no external device connected.

I Remote shutdown cable assembly

! Remote shutdown connection is only available for Europe.

NO	5	6
Function	REFGEN	COM/DRM0




Step1
Instructions for quick installation

Step2
SOP of battery connection

Step3
Wi-Fi configuration instruction

J Wiring system for ES series hybrid inverter

Note: This diagram indicates wiring structure of ES series hybrid inverter, not the electric wiring standard.



Please select Breaker according to the specification below

Inverter	①	②	③	④	⑤
GW3648D-ES	125A/60V DC breaker	25A/400V AC breaker	16A/230V AC breaker	Depends on household loads	
GW5048D-ES		32A/400V AC breaker	20A/230V AC breaker		

1. For batteries with attached breaker, the external DC breaker could be omitted.
2. Only for lithium battery which has BMS communication.
3. Please use CT A for L1, CT B for L2 and CT C for L3. And follow "House(K) → Grid(L)" direction to do the connection. Otherwise there will be an error reminded by PV Master App.


Step 2. SOP of battery connection with EM inverter

Note: This manual only tells connection methods between battery and GoodWe inverters. Other operations on battery, please refer to battery user manual. This manual only includes some battery models, not all of them. Battery models are subject to change without prior notice.


1. BYD

For BYD B-BOX series with hybrid inverter.

A


 Make sure that the inverter and the battery pack is turned off before connecting the battery pack to the inverter.

Note: ADDR setting of battery is required if there are more than one battery banks connected to the inverter. Please refer to battery user manual for detailed instruction.




B

To connect the cables coming from the inverter to the BYD battery pack, take the following steps. Connect the power cables to the terminal block of BYD battery pack. Connect the negative cable to "P-" and the positive cable to "P+".




D

To communication cable for battery is attached on the inverter. Please use this cable as battery communication cable.




C

1. Cut off the plastic skin of the cable.
2. Put the cable through the terminal cover plate.
3. Plug the metal part into the battery R-type terminal (25-8) which in the accessories box, the crimp the terminal tightly.
4. Connect the power cable to the terminal block of the hybrid inverter and restore the inverter terminal cover plate.




F

On PV Master, should choose the right battery type used in your system by "Battery Model" selection or battery communication will fail.




E

The other side of "To Battery" cable should be connected to CAN port of BYD BMU box.



G


After all connection and setting done, please check if battery communication is OK on PV Master→Param→BMS Status, which should be "Normal".




2. BYD

For BYD LV series with hybrid inverter.


A

 Make sure that the inverter and the battery pack is turned off before connecting the battery pack to the inverter.




B

To connect the cables coming from the inverter to the BYD battery pack, take the following steps. Connect the power cables to the terminal block of BYD battery pack. Connect the negative cable to "-" and the positive cable to "+".




C

1. Cut off the plastic skin of the cable.
2. Put the cable through the terminal cover plate.
3. Plug the metal part into the battery R-type terminal (25-8) which in the accessories box, the crimp the terminal tightly.
4. Connect the power cable to the terminal block of the hybrid inverter and restore the inverter terminal cover plate.




D

To communication cable for battery is attached on the inverter. Please use this cable as battery communication cable.




E

The other side of "To Battery" cable should be connected to CAN port of BYD BCU.




F

On PV Master, should choose the right battery type used in your system by "Battery Model" selection or battery communication will fail.




G

After all connection and setting done, please check if battery communication is OK on PV Master→Param→BMS Status, which should be "Normal".




3. GCL


For GCL E-KwBe series with hybrid inverter.

A  Make sure that the inverter and the battery pack is turned off before connecting the battery pack to the inverter.

Note: If connect multi batteries (max 4 pieces), please refer to battery user manual to do configuration on batteries.




B To connect the cables coming from the inverter to the GCL battery pack, take the following steps. Connect the power cables to the terminal block of GCL battery pack. Connect the negative cable to "-" and the positive cable to "+".




C

1. Cut off the plastic skin of the cable.
2. Put the cable through the terminal cover plate.
3. Plug the metal part into the battery R-type terminal (25-8) which in the accessories box, then crimp the terminal tightly.
4. Connect the power cable to the terminal block of the hybrid inverter and restore the inverter terminal cover plate.




D To communication cable for battery is attached on the inverter. Please use this cable as battery communication cable.



F On PV Master, should choose the right battery type used in your system by "Battery Model" selection or battery communication will fail.

Select Battery Model	
GCL	
GCL 5.6KWH	<input checked="" type="checkbox"/>
GCL 5.6KWH*2	<input type="checkbox"/>
GCL 5.6KWH*3	<input type="checkbox"/>

E The other side of "To Battery" cable should be connected to CAN port of BYD BMU box.





G After all connection and setting done, please check if battery communication is OK on PV Master→Param→BMS Status, which should be "Normal".

Param	
Battery (GCL 5.6KWH)	
Battery Status	SOC: 80%, Discharge
Battery Data	51.1V / 0.3A / 0.020k
BMS Status	Normal
SOH (From BMS)	100.0%
Charge Current Limit (From BMS)	90.0A
Discharge Current Limit (From BMS)	50.0A
Warning (From BMS)	Normal
Temperature (From BMS)	25.0°C


4. LG

For LG RESU series hybrid inverter.

A  Make sure that the inverter and the battery pack is turned off before connecting the battery pack to the inverter.




B Remove the top cover. Hold both sides of the top cover and pull it upwards.




C Connect the power cables to the terminal block through the grommet.

1. Remove the terminal cover plate, which is placed over the terminal block.
2. Plug the metal part into the battery R-type terminal (25-8) which in Cable Accessories for LG battery, then crimp the terminal tightly.
3. Restore the battery terminal cover plate.




D


1. Cut off the plastic skin of the cable.
2. Put the cable through the terminal cover plate.
3. Plug the metal part into the battery R-type terminal (25-8) which in the accessories box, then crimp the terminal tightly.
4. Connect the power cable to the terminal block of the hybrid inverter and restore the inverter terminal cover plate.




E The communication cable for battery is attached on the inverter. Please use this cable as battery communication cable.



F The other side of "To Battery" cable should be connected to CAN port on the top side of LG battery.



G There are three DIP switches and three rotary switches on battery, which should be set as below.



Note: RESU6.4EX has no DIP switches, you can ignore this part.

H On PV Master, should choose the right battery type used in your system by "Battery Model" selection or battery communication will fail.


Select Battery Model	
LG	
LG RESU 6.4EX	<input type="checkbox"/>
GCL RESU 6.5	<input checked="" type="checkbox"/>
GCL RESU 3.3	<input type="checkbox"/>


I After all connection and setting done, please check if battery communication is OK on PV Master→Param→BMS Status, which should be "Normal".

Param	
Battery (LG RESU 6.5)	
Battery Status	SOC: 80%, Discharge
Battery Data	51.1V / 0.3A / 0.020k
BMS Status	Normal
SOH (From BMS)	100.0%
Charge Current Limit (From BMS)	80.0A
Discharge Current Limit (From BMS)	80.0A
Warning (From BMS)	Normal
Temperature (From BMS)	25.0°C


5. Pylon

For Pylon US2000&US3000 series hybrid inverter.

A  Make sure that the inverter and the battery pack is turned off before connecting the battery pack to the inverter.




B To connect the cables coming from the inverter to the GCL battery pack, take the following steps. Connect the negative cable to the black terminal and the positive cable to the orange terminal.




C

1. Cut off the plastic skin of the cable.
2. Put the cable through the terminal cover plate.
3. Plug the metal part into the battery R-type terminal (25-8) which in GoodWe accessories box, then crimp the terminal tightly.
4. Connect the power cable to the terminal block of the hybrid inverter and restore the inverter terminal cover plate.




D The communication cable for battery is attached on the inverter. Please use this cable as battery communication cable.



E The other side of "To Battery" cable should be connected CAN port of Pylon battery.




F On PV Master, should choose the right battery type used in your system by Battery Model selection or battery communication will fail.



Battery Model	Status
PYLON	^
PYLON US2000B*3	☑
PYLON US2000B*4	☑
PYLON US2000Plus*1	☑


G After all connections and settings are done, please check if battery communication is OK on PV Master → Param → BMS Status, which should be "Normal"




Param	Value
Battery (PYLON US2000Plus*1)	
Battery Status	SOC 91%, Discharge
Battery Data	53.2V / 6.7A / 0.54kW
BMS Status	Normal
SOH (From BMS)	100.0%
Charge Current Limit (From BMS)	101A
Discharge Current Limit (From BMS)	101A
Warning (From BMS)	Normal
Temperature (From BMS)	26.0°C

6. Dyness

For Dyness B4850 series hybrid inverter.

A  Make sure that the inverter and the battery pack is turned off before connecting the battery pack to the inverter.



Switch


Note: ADDR setting of battery is required if there are more than one battery banks connected to the inverter. Please refer to battery user manual for detailed instruction.

B To connect the cables coming from the inverter to the Dyness battery pack, take the following steps. Connect the negative cable to the black terminal and the psaitive cable to the Red terminal.




C


1. Cut off the plastic skin of the cable.
2. Put the cable through the terminal cover plate.
3. Plug the metal part into the battery R-type terminal (25-8) which in GoodWe accessories box, then crimp the terminal tightly.
4. Connect the power cable to the terminal block of the hybrid inverter and restore the inverter terminal cover plate.




D The communication cable for battery is attached on the inverter. Please use this cable as battery communication cable.



E The other side of "To Battery" cable should be connected CAN port of Dyness battery.




F On PV Master, should choose the right battery type used in your system by "Battery Model" selection or battery communication will fail.



Battery Model	Status
DYNESS	^
B4850*1	☑
B4850*2	☑
B4850*3	☑

G After all connections and settings are done, please check if battery communication is OK on PV Master → Param → BMS Status, which should be "Normal"



Param	Value
Battery (B4850*2)	
Battery Status	SOC 90%, Discharge
Battery Data	49.9V / 6.9A / 0.64kW
BMS Status	Normal
SOH (From BMS)	100.0%
Charge Current Limit (From BMS)	50A
Discharge Current Limit (From BMS)	50A
Warning (From BMS)	Normal
Temperature (From BMS)	29.0°C

Step1
Instructions for quick installation

Step2
SOP of battery connection

Step3
Wi-Fi configuration instruction

7. Alpha


For Alpha Smile5-Bat series hybrid inverter.

A  Make sure that the inverter and the battery pack is turned off before connecting the battery pack to the inverter.




Note: If connect multi batteries(max 40 pieces),please refer to battery user manual to do configuration on batteries. The battery indicator is off.

B To connect the cables coming from the inverter to the SMILE5 battery pack, take the following steps. Connect the negative cable to the black terminal and the psaitive cable to the Red terminal.




C


1. Cut off the plastic skin of the cable.
2. Put the cable through the terminal cover plate.
3. Plug the metal part into the battery R-type terminal (25-8) which in GoodWe accessories box, then crimp the terminal tightly.
4. Connect the power cable to the terminal block of the hybrid inverter and restore the inverter terminal cover plate.




D The communication cable for battery is attached on the inverter. Please use this cable as battery communication cable.




F On PV Master, should choose the right battery type used in your system by Battery type used in your system by "Battery Model selection" or battery communication will fail.



E The other side of "To Battery" cable should be connected CAN port of Pylon battery.



G After all connections and settings are done, please check if battery communication is OK on PV Master → Param → BMS Status, which should be "Normal"



Step1
Instructions for quick installation

Step2
SOP of battery connection

Step3
Wi-Fi configuration instruction


Step 3. Wi-Fi configuration instruction

Note: Wi-Fi configuration could also be done on PV Master App. For details, please download "PV Master Operation Introduction" from www.goodwe.com

- A Preparation**
1. Power Wi-Fi inverter (or Power on inverter) on.
 2. Power router on.

B Connect to "Solar-WiFi"


B-3: Enter User name: admin, Password:admin, click OK



C Preparation

Click "Start Setup"

The Wi-Fi module refers to "Device information" column left.



Please select you current wireless network

SSID	AUTH/ENCY	RSSI	Channel
<input type="radio"/> WiFi_Burn-in	WPAPSK/WPA2PSK/TKIP/AES	65	1
<input type="radio"/> WiFi_Burn-in	WPAPSK/WPA2PSK/TKIP/AES	100	1
<input type="radio"/> WiFi_Burn-in	WPAPSK/WPA2PSK/TKIP/AES	70	1
<input type="radio"/> WiFi_Burn-in-2	WPAPSK/WPA2PSK/TKIP/AES	72	1
<input type="radio"/> WiFi_Burn-in-2	WPAPSK/WPA2PSK/TKIP/AES	100	1
<input type="radio"/> WiFi_Burn-in-2	WPAPSK/WPA2PSK/TKIP/AES	70	1
<input type="radio"/> WiFi_Burn-in-3	WPAPSK/WPA2PSK/TKIP/AES	76	1
<input type="radio"/> WiFi_Burn-in-3	WPAPSK/WPA2PSK/TKIP/AES	76	1

* Help: When RSSI of the selected Wi-Fi network is lower than 15%, the connection may be unstable. Please select other available network or shorten the distance between the device and router. If you wireless router does not broadcast SSID, please click "Next" and add a wireless network manually.


Back Next

D Connect to "Solar-WiFi"

Fill in router password and click "Next".

Please make sure all parameters of wireless network are matched with the router's, including password.

Note: If the Wi-Fi module fail to connect to network after enter the right password. It's possible that there is special characters not supported by module in the hotspot passwords.



Add wireless network manually:

Network name (SSID) Router Name

Encryption method WPA/WPA2-PSK

Encryption algorithm AES

Please enter the wireless network password:

Password (8-63 bytes) Router Password

Remember the password (R)

* Note: case sensitive for SSID and Password. Please make sure all parameters of wireless network are matched with router, including password.

Back Next

Save success!

Click "Complete", the current configuration will take effect after restart.

If you still need to configure the other pages of information, please go to complete your required configuration.

Configuration is completed, you can log on the Management page to restart device by click on "OK" button.

Confirm or complete?

Back Complete

Note: The "Solar-WiFi" signal will disappear after inverter is connected to WiFi router. Turn off the router or do Wi-Fi reload operation via button on inverter if you need to reconnect to "Solar-WiFi" once again.

E Troubleshooting

No.	Problem	Checking items
1	Cannot Find Solar-WiFi Signal	<ol style="list-style-type: none"> 1. Make sure inverter is powered on; 2. Move your smart device closer to inverter; 3. Restart inverter; 4. Do "WiFi Reload" operation refer to user manual.
2	Cannot connect to Solar-WiFi Signal	<ol style="list-style-type: none"> 1. Try password: 12345678; 2. Restart inverter; 3. Make sure there is no other device connected to Solar-WiFi; 4. Do "WiFi Reload" operation and try again.
3	Cannot login website 10.10.100.253	<ol style="list-style-type: none"> 1. Make sure user name and password you use are both admin; 2. Do "WiFi Reload" operation and try again; 3. Try another browser (suggest use Google, FireFox, IE, Safari etc.); 4. Make sure website you log in is 10.10.100.253
4	Cannot find router SSID	<ol style="list-style-type: none"> 1. Move router closer to inverter or use a Wi-Fi repeater device; 2. Connect to router and login the setting page to check the channel it uses. Please make sure the channel is not bigger than 13. Otherwise, modify it.
5	Cannot Find Solar-WiFi Signal	<ol style="list-style-type: none"> 1. Restart inverter. 2. Connect to Solar-WiFi and login again, check the "SSID", "Security Mode", "Encryption Type" and "Pass Phrase" is matching with that of router or not; 3. Connect to router and login to check if the connection reaches the maximum amount or not, and to check the channel of it uses. Please make sure the channel is not bigger than 13. Otherwise, modify it; 4. Restart router; 5. Move router closer to inverter or use a Wi-Fi repeater device.
6	After configuration, WiFi Led on inverter blink four times repeatedly	<ol style="list-style-type: none"> 1. Connect to the router and visit the portal www.semsportal.com, Check the portal is available or not; 2. Restart router and inverter;